

Alternative Control Measure

12-7-21

Area Inlet protection

Description: Using Dura wattles (or similar product) as area inlet sediment protection.

Purpose: Minimize sediment discharging into inlet.

Installation: Remove grate, place flap into inlet, replace grate, overlap wattle on the down slope side or splice wattles into each other.

Maintenance: Remove any sediment from the wattle when it reaches $\frac{1}{2}$ its height or replace if damaged.

